



Steam Heating Tubes DHD, DHW, DHU and DHR


DHD
Steam heating tube of stainless steel for types 60-170




DHW 100 / DHW 150
Steam heating tube of stainless steel
DHW100 for types 60,70,100
DHW150 for types 80,150,170



DHU
Steam heating tube of stainless steel for all types



DHR 50 / DHR155
Aluminium-radiator with stainless steel steampipe
DHR 50 for types 25,48
DHR 155 for types 60 bis 170



Installation:
Drill 2 holes into INTERTEC-protection-box, insert wall bushing WDD12/25, push heating tube from the inside outwards and connect the ends with steam- and condensate conduit.

Mounting fittings are not included